

MULTI-PURPOSE CONTROL APPLICATION
(par. 0.1 = 6)

CONTENTS

5 Multi-purpose Control Application 5-1

5.1 General 5-2

5.2 Control I/O 5-2

5.3 Control signal logic 5-3

5.4 Parameters Group 1 5-4

5.4.1 Parameter table 5-4

5.4.2 Description of Group1 par. 5-5

5.5 Special parameters, Groups 2-8 5-9

5.5.1 Parameter tables 5-9

5.5.2 Description of Group 2 par. 5-16

5 Multi-purpose Control Application

5.1 General

In the Multi-purpose control application the frequency reference can be selected from the analog inputs, the joystick control, the motorized (digital) potentiometer and a mathematical function of the analog inputs. Multi-step speeds and jogging speed can also be selected if digital inputs are programmed

for these functions.

Digital inputs DIA1 and DIA2 are reserved for Start/stop logic. Digital inputs DIA3—DIB6 are programmable for multi-step speed select, jogging speed select, motorized (digital) potentiometer, external fault, ramp time select, ramp prohibit, fault reset and DC-brake command function. All outputs are freely programmable.

5.2 Control I/O




Figure 5.2-1 Default I/O configuration and connection example of the Multi-purpose Control Application.

5.3 Control signal logic

The logic flow of the I/O-control signals and pushbutton signals from the panel is shown in figure 5.3-1.














Figure 5.3-1 Control signal logic of the Multipurpose Control Application. Switch positions shown are based on the factory settings.

5.4 Basic parameters, Group 1

5.4.1 Parameter table

Code	Parameter	Range	Step	Default	Custom	Description	Page
1.1	Minimum frequency	0— f_{max}	1 Hz	0 Hz			5-5
1.2	Maximum frequency	f_{min} —120/500Hz	1 Hz	60 Hz	*)		5-5
1.3	Acceleration time 1	0.1—3000.0 s	0.1 s	3.0 s		Time from f_{min} (1. 1) to f_{max} (1. 2)	5-5
1.4	Deceleration time 1	0.1—3000.0 s	0.1 s	3.0 s		Time from f_{max} (1. 2) to f_{min} (1. 1)	5-5
1.5	Reference selection 	0—9	1	0		0 = V_{in} 1 = I_{in} 2 = $V_{in} + I_{in}$ 3 = $V_{in} - I_{in}$ 4 = $I_{in} - V_{in}$ 5 = $V_{in} * I_{in}$ 6 = V_{in} joystick control 7 = I_{in} joystick control 8 = Signal from internal motor pot. 9 = Signal from internal motor pot. reset if SV9000 is stopped	5-5
1.6	Jog speed reference 	f_{min} — f_{max} (1. 1) (1. 2)	0.1 Hz	5.0 Hz			5-6
1.7	Current limit	0.1—2.5 x I_{NCX}	0.1 A	1.5 x I_{NCX}		Output current limit [A] of the unit	5-6
1.8	V/Hz ratio selection 	0—2	1	0		0 = Linear 1 = Squared 2 = Programmable V/Hz ratio	5-6
1.9	V/Hz optimisation 	0—1	1	0		0 = None 1 = Automatic torque boost	5-8
1.10	Nominal voltage of the motor 	180—690 V	1 V	230 V 380 V 480 V 575 V		Voltage code 2 Voltage code 4 Voltage code 5 Voltage code 6	5-8
1.11	Nominal frequency of the motor 	30—500 Hz	1 Hz	60 Hz		f_n from the nameplate of the motor	5-8
1.12	Nominal speed of the motor 	1—20000 rpm	1 rpm	1720 rpm **)		n_n from the nameplate of the motor	5-8
1.13	Nominal current of the motor 	2.5 x I_{NCX}	0.1 A	I_{NCX}		I_n from the nameplate of the motor	5-8
1.14	Supply voltage 	208—240 380—440 380—500 525—690		230 V 380 V 480 V 575 V		Voltage code 2 Voltage code 4 Voltage code 5 Voltage code 6	5-8
1.15	Parameter conceal	0—1	1	0		Visibility of the parameters: 0 = All parametergroups visible 1 = Only group 1 is visible	5-8
1.16	Parameter value lock	0—1	1	0		Disables parameter changes: 0 = Changes enabled 1 = Changes disabled	5-8

Note!  = Parameter value can be changed only when the drive is stopped.

*) If 1. 2 > motor synchr. speed, check suitability for motor and drive system.

Selecting 120/500 Hz range see page 5-5.

**) Default value for a four pole motor and a nominal size drive.

Table 5.4-1 Group 1 basic parameters.

5.4.2 Description of Group 1 parameters

1. 1, 1. 2 Minimum / maximum frequency

Defines frequency limits of the drive.

The default maximum value for parameters 1. 1 and 1. 2 is 120 Hz. By setting 1. 2 = 120 Hz when the drive is stopped (RUN indicator not lit) parameters 1. 1 and 1. 2 are changed to 500 Hz. At the same time the panel reference resolution is changed from 0.01 Hz to 0.1 Hz.

Changing the max. value from 500 Hz to 120 Hz is done by setting parameter 1. 2 = 119 Hz when the drive is stopped.

1. 3, 1. 4 Acceleration time 1, deceleration time 1:

These limits correspond to the time required for the output frequency to accelerate from the set minimum frequency (par. 1. 1) to the set maximum frequency (par. 1. 2).

1. 5 Reference selection

- 0** Analog voltage reference from terminals 2—3, e.g. a potentiometer
- 1** Analog current reference from terminals 4—5, e.g. a transducer.
- 2** Reference is the formed by adding the values of the analog inputs
- 3** Reference is the formed by subtracting the voltage input (V_{in}) value from the current input (I_{in}) value.
- 4** Reference is the formed by subtracting the current input (I_{in}) value from the voltage input (V_{in}) value.
- 5** Reference is the formed by multiplying the values of the analog inputs
- 6** Joystick control from the voltage input (V_{in}).

Signal range	Max reverse speed	Direction change	Max forward speed
0—10 V	0 V	5 V	+10 V
Custom	Par. 2. 7 x 10V	In the middle of custom range	Par. 2. 8 x 10 V
-10 V—+10 V	-10 V	0 V	+10 V

Warning! Use only -10V—+10 V signal range. If a custom or 0—10 V signal range is used, the drive will run at the max. reverse speed if the reference signal is lost.



7 Joystick control from the current input (I_{in}).

Signal range	Max reverse speed	Direction change	Max forward speed
0—20 mA	0 mA	10 mA	20 mA
Custom	Par. 2. 13 x 20 mA	In the middle of custom range	Par. 2. 14 x 20 mA
4—20 mA	4 mA	12 mA	20 mA

Warning! Use only 4—20 mA signal range. If a custom or 0—20 mA signal range is used, the drive will run at the max. reverse speed if the control signal is lost. Set the reference fault (par. 7. 2) active when the 4—20 mA range is used, then the drive will stop with a reference fault if the reference signal is lost.



Note! When joystick control is used, the direction control is generated from the joystick reference signal. See figure 5.4-1.

Analog input scaling, parameters 2. 16—2. 19 are not used when joystick control is used.




Fig. 5.4-1 Joystick control V_{in} signal -10 V—+10 V.

- 8 Reference value is changed with digital input signals DIA4 and DIA5.
 - switch in DIA3 closed = frequency reference increases
 - switch in DIA4 closed = frequency reference decreases
 Speed of the reference change can be set with the parameter 2. 20.
- 9 Same as setting 8 but the reference value is set to the minimum frequency (par. 1. 1) each time the SV9000 is stopped.

When the value of parameter 1. 5 is set to 8 or 9, the value of parameters 2. 4 and 2. 5 are automatically set to 11.

1. 6 Jog speed reference

Parameter value defines the jog speed selected with the digital input

1. 7 Current limit

This parameter determines the maximum motor current that the SV9000 will provide short term.

1. 8 V/Hz ratio selection

Linear: The voltage of the motor changes linearly with the frequency in the constant flux area from 0 Hz to the field weakening point (par. 6. 3) where a constant voltage (nominal value) is also supplied to the motor. See figure 5.4.-2. A linear V/Hz ratio should be used in constant torque applications.

0

This default setting should be used if there is no special requirement for another setting.

Squared: 1 The voltage of the motor changes following a squared curve form with the frequency in the area from 0 Hz to the field weakening point (par. 6. 3) where the nominal voltage is also supplied to the motor. See figure 5.4.-2.

The motor runs undermagnetized below the field weakening point and produces less torque and electromechanical noise. A squared V/Hz ratio can be used in applications where the torque demand of the load is proportional to the square of the speed, e.g. in centrifugal fans and pumps.




Figure 5.4.-2 Linear and squared V/Hz curves.

Programm. V/Hz curve 2 The V/Hz curve can be programmed with three different points. The parameters for programming are explained in the chapter 5.5.2. Programmable V/Hz curve can be used if the other settings do not satisfy the needs of the application. See figure 5.4.-3.




Figure 5.4-3 Programmable V/Hz curve.

1. 9 V/Hz optimization

Automatic torque boost The voltage to the motor changes automatically which makes the motor produce sufficient torque to start and run at low frequencies. The voltage increase depends on the motor type and horsepower.

Automatic torque boost can be used in applications where starting torque due to starting friction is high, e.g. in conveyors.

NOTE!

In high torque - low speed applications - it is likely the motor will overheat.

If the motor has to run prolonged time under these conditions, special attention must be paid to cooling the motor. Use external cooling for the motor if the temperature rise is too high.

1. 10 Nominal voltage of the motor

Find this value U_n from the nameplate of the motor.

This parameter sets the voltage at the field weakening point, parameter 6. 4, to $100\% \times U_{n\text{motor}}$.

1. 11 Nominal frequency of the motor

Find this value f_n from the nameplate of the motor.

This parameter sets the frequency of the field weakening point, parameter 6. 3, to the same value.

1. 12 Nominal speed of the motor

Find this value n_n from the nameplate of the motor.

1. 13 Nominal current of the motor

Find the value I_n from the nameplate of the motor.

The internal motor protection function uses this value as a reference value.

1. 14 Supply voltage

Set parameter value according to the nominal voltage of the supply.

Values are pre-defined for voltage codes 2, 4, 5 and 6. See table 5.4-1.

1. 15 Parameter conceal

Defines which parameter groups are available:

0 = all parameter groups are visible

1 = only group 1 is visible

1. 16 Parameter value lock

Defines access to the changes of the parameter values:

0 = parameter value changes enabled






1 = parameter value changes disabled


To adjust more of the functions of the Multipurpose application, see chapter 5.5 to modify the parameters of Groups 2—8.

5.5 Special parameters, Groups 2—8

5.5.1 Parameter tables

Group 2, Input signal parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
2.1	Start/Stop logic selection 	0—3	1	0		DIA1	5-16
						DIA2	
						0 = Start forward 1 = Start/Stop 2 = Start/Stop 3 = Start pulse	
						Start reverse Reverse Run enable Stop pulse	
2.2	DIA3 function (terminal 10) 	0—9	1	7		0 = Not used 1 = Ext. fault, closing contact 2 = External fault, opening contact 3 = Run enable 4 = Acc./dec. time selection 5 = Reverse 6 = Jog speed 7 = Fault reset 8 = Acc./dec. operation prohibit 9 = DC-braking command	5-17
2.3	DIB4 function (terminal 14) 	0—10	1	6		0 = Not used 1 = Ext. fault, closing contact 2 = External fault, opening contact 3 = Run enable 4 = Acc./dec. time selection 5 = Reverse 6 = Jog speed 7 = Fault reset 8 = Acc./dec. operation prohibit 9 = DC-braking command 10 = Multi-Step speed select 1	5-18
2.4	DIB5 function (terminal 15) 	0—11	1	1		0 = Not used 1 = Ext. fault, closing contact 2 = External fault, opening contact 3 = Run enable 4 = Acc./dec. time selection 5 = Reverse 6 = Jog speed 7 = Fault reset 8 = Acc./dec. operation prohibit 9 = DC-braking command 10 = Multi-Step speed select 2 11 = Motorised pot. speed up	5-18
2.5	DIB6 function (terminal 16) 	0—11	1	4		0 = Not used 1 = Ext. fault, closing contact 2 = External fault, opening contact 3 = Run enable 4 = Acc./dec. time selection 5 = Reverse 6 = Jog speed 7 = Fault reset 8 = Acc./dec. operation prohibit 9 = DC-braking command 10 = Multi-Step speed select 3 11 = Motorised pot. speed down	5-18
2.6	V _{in} signal range	0—2	1	0		0 = 0—10 V 1 = Custom setting range 2 = -10—+10 V (can be used only with Joystick control)	5-19

Note! 


= Parameter value can be changed only when the drive is stopped.

(Continues)

Code	Parameter	Range	Step	Default	Custom	Description	Page
2.7	V _{in} custom setting min.	0.00-100.00%	0.01%	0.00%			5-19
2.8	V _{in} custom setting max.	0.00-100.00%	0.01%	100.00%			5-19
2.9	V _{in} signal inversion	0—1	1	0		0 = Not inverted 1 = Inverted	5-19
2.10	V _{in} signal filter time	0.00—10.00 s	0.01 s	0.10 s		0 = No filtering	5-19
2.11	I _{in} signal range	0—2	1	0		0 = 0—20 mA 1 = 4—20 mA 2 = Custom setting range	5-19
2.12	I _{in} custom setting minim.	0.00-100.00%	0.01%	0.00%			5-20
2.13	I _{in} custom setting maxim.	0.00-100.00%	0.01%	100.00%			5-20
2.14	I _{in} signal inversion	0—1	1	0		0 = Not inverted 1 = Inverted	5-20
2.15	I _{in} signal filter time	0.01—10.00 s	0.01 s	0.10 s		0 = No filtering	5-20
2.16	V _{in} minimum scaling	-320.00%— +320.00 %	0.01	0.00%		0% = no minimum scaling	5-20
2.17	V _{in} maximum scaling	-320.00%— +320.00 %	0.01	100.00%		100% = no maximum scaling	5-20
2.18	I _{in} minimum scaling	-320.00%— +320.00%	0.01	0.00%		0% = no minimum scaling	5-20
2.19	I _{in} maximum scaling	-320.00%— +320.00 %	0.01	100.00%		100% = no maximum scaling	5-20
2.20	Free analog input, signal selection	0—2	1	0		0 = Not use 1 = V _{in} (analog voltage input) 2 = I _{in} (analog current input)	5-21
2.21	Free analog input, function	0—4	1	0		0 = No function 1 = Reduces current limit (par. 1.7) 2 = Reduces DC-braking current 3 = Reduces acc. and decel. times 4 = Reduces torque supervis. limit	5-21
2.22	Motorized digital potentiometer ramp time	0.1—2000.0 Hz/s	0.1 Hz/s	10.0 Hz/s			5-22




Group 3, Output and supervision parameters


Code	Parameter	Range	Step	Default	Custom	Description	Page
3.1	Analog output function	0—7	1	1		0 = Not used Scale 100% 1 = O/P frequency (0—f _{max}) 2 = Motor speed (0—max. speed) 3 = O/P current (0—2.0 x I _{nCX}) 4 = Motor torque (0—2 x T _{nMot}) 5 = Motor power (0—2 x P _{nMot}) 6 = Motor voltage (0—100% x U _{nMot}) 7 = DC-link volt. (0—1000 V)	5-23
3.2	Analog output filter time	0.00-10.00s	0.01 s	1.00 s			5-23
3.3	Analog output inversion	0—1	1	0		0 = Not inverted 1 = Inverted	5-23
3.4	Analog output minimum	0—1	1	0		0 = 0 mA 1 = 4 mA	5-23
3.5	Analog output scale	10—1000%	1%	100%			5-23

Note! 

= Parameter value can be changed only when the drive is stopped.

(Continues)

Code	Parameter	Range	Step	Default	Custom	Description	Page
3. 6	Digital output function 	0—21	1	1		0 = Not used 1 = Ready 2 = Run 3 = Fault 4 = Fault inverted 5 = SV9000 overheat warning 6 = External fault or warning 7 = Reference fault or warning 8 = Warning 9 = Reversed 10 = Jogging speed selected 11 = At speed 12 = Motor regulator activated 13 = Output freq. limit superv. 1 14 = Output freq. limit superv. 2 15 = Torque limit supervision 16 = Reference limit supervision 17 = External brake control 18 = Control from I/O terminals 19 = Drive temperature limit supervision 20 = Unrequested rotation direction 21 = External brake control inverted	5-24
3. 7	Relay output 1 function 	0—21	1	2		As parameter 3. 6	5-24
3. 8	Relay output 2 function 	0—21	1	3		As parameter 3. 6	5-24
3. 9	Output freq. limit 1 supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	5-24
3. 10	Output freq. limit 1 supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			5-24
3. 11	Output freq. limit 2 supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	5-24
3. 12	Output freq. limit 2 supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			5-24
3. 13	Torque limit supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	5-25
3. 14	Torque limit supervision value	-200.0—200.0% $\times T_{nCX}$	0.1%	100.0%			5-25
3. 15	Reference limit supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	5-25
3. 16	Reference limit supervision value	0.0— f_{\max} (par. 1. 2)	0.1 Hz	0.0 Hz			5-25
3. 17	Extern. brake Off-delay	0.0—100.0 s	0.1 s	0.5 s			5-25
3. 18	Extern. brake On-delay	0.0—100.0 s	0.1 s	1.5 s			5-25
3. 19	Drive temperature limit supervision function	0—2	1	0		0 = No 1 = Low limit 2 = High limit	5-25
3. 20	Drive temperature limit value	-10—+75°C	1°C	+40°C			5-25


Note! 


= Parameter value can be changed only when the drive is stopped.

(Continues)

Code	Parameter	Range	Step	Default	Custom	Description	Page
3.21	I/O-expander board (opt.) analog output content	0—7	1	3		See parameter 3. 1	5-23
3.22	I/O-expander board (opt.) analog output filter time	0.00—10.00 s	0.01	1.00 s		See parameter 3. 2	5-23
3.23	I/O-expander board (opt.) analog output inversion	0—1	1	0		See parameter 3. 3	5-23
3.24	I/O-expander board (opt.) analog output minimum	0—1	1	0		See parameter 3. 4	5-23
3.25	I/O-expander board (opt.) analog output scale	10—1000%	1	100%		See parameter 3. 5	5-23

Group 4, Drive control parameters







Code	Parameter	Range	Step	Default	Custom	Description	Page
4. 1	Acc./Dec. ramp 1 shape	0.0—10.0 s	0.1 s	0.0 s		0 = Linear >0 = S-curve acc./dec. time	5-26
4. 2	Acc./Dec. ramp 2 shape	0.0—10.0 s	0.1 s	0.0 s		0 = Linear >0 = S-curve acc./dec. time	5-26
4. 3	Acceleration time 2	0.1—3000.0 s	0.1 s	10.0 s			5-27
4. 4	Deceleration time 2	0.1—3000.0 s	0.1 s	10.0 s			5-27
4. 5	Brake chopper 	0—2	1	0		0 = Brake chopper not in use 1 = Brake chopper in use 2 = External brake chopper	5-27
4. 6	Start function	0—1	1	0		0 = Ramp 1 = Flying start	5-27
4. 7	Stop function	0—1	1	0		0 = Coasting 1 = Ramp	5-27
4. 8	DC-braking current	0.15—1.5 x I _{NCX} (A)	0.1 A	0.5 x I _{NCX}			5-27
4. 9	DC-braking time at Stop	0.00-250.00s	0.01 s	0.00 s		0 = DC-brake is off at Stop	5-28
4. 10	Execute frequency of DC-brake during ramp Stop	0.1—10.0 Hz	0.1 Hz	1.5 Hz			5-29
4. 11	DC-brake time at Start	0.00-25.00 s	0.01 s	0.00 s		0 = DC-brake is off at Start	5-29
4. 12	Multi-step speed reference 1	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	10.0 Hz			5-29
4. 13	Multi-step speed reference 2	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	15.0 Hz			5-29
4. 14	Multi-step speed reference 3	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	20.0 Hz			5-29
4. 15	Multi-step speed reference 4	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	25.0 Hz			5-29
4. 16	Multi-step speed reference 5	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	30.0 Hz			5-29
4. 17	Multi-step speed reference 6	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	40.0 Hz			5-29
4. 18	Multi-step speed reference 7	f _{min} —f _{max} (1. 1) (1. 2)	0.1 Hz	50.0 Hz			5-29


Note!  = Parameter value can be changed only when the drive is stopped.

Group 5, Prohibit frequency parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
5.1	Prohibit frequency range 1 low limit	f_{\min} — par. 5.2	0.1 Hz	0.0 Hz			5-29
5.2	Prohibit frequency range 1 high limit	f_{\min} — f_{\max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 1 is off	5-29
5.3	Prohibit frequency range 2 low limit	f_{\min} — par. 5.4	0.1 Hz	0.0 Hz			5-29
5.4	Prohibit frequency range 2 high limit	f_{\min} — f_{\max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 2 is off	5-29
5.5	Prohibit frequency range 3 low limit	f_{\min} — par. 5.6	0.1 Hz	0.0 Hz			5-29
5.6	Prohibit frequency range 3 high limit	f_{\min} — f_{\max} (1.1) (1.2)	0.1 Hz	0.0 Hz		0 = Prohibit range 3 is off	5-29

Group 6, Motor control parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
6.1	Motor control mode 	0—1	1	0		0 = Frequency control 1 = Speed control	5-29
6.2	Switching frequency	1.0—16.0 kHz	0.1 kHz	10/3.6 kHz		Dependant on Hp rating	5-30
6.3	Field weakening point 	30—500 Hz	1 Hz	Param. 1.11			5-30
6.4	Voltage at field weakening point 	15—200% $\times U_{nmot}$	1%	100%			5-30
6.5	V/Hz curve mid point frequency 	0.0— f_{\max}	0.1 Hz	0.0 Hz			5-30
6.6	V/Hz curve mid point voltage 	0.00—100.00% $\times U_{nmot}$	0.01%	0.00 %			5-30
6.7	Output voltage at zero frequency 	0.00—100.00% $\times U_{nmot}$	0.01%	0.00 %			5-30
6.8	Overvoltage controller	0—1	1	1		0 = Controller is not operating 1 = Controller is operating	5-31
6.9	Undervoltage controller	0—1	1	1		0 = Controller is not operating 1 = Controller is operating	5-31

Note!  = Parameter value can be changed only when the drive is stopped.

Group 7, Protections

Code	Parameter	Range	Step	Default	Custom	Description	Page
7.1	Response to reference fault	0—2	1	0		0 = No action 1 = Warning 2 = Fault, stop according to par 4.7 3 = Fault, always coasting stop	5-31
7.2	Response to external fault	0—2	1	2		0 = No action 1 = Warning 2 = Fault, stop according to par 4.7 3 = Fault, always coasting stop	5-31
7.3	Phase supervision of the motor	0—2	2	2		0 = No action 2 = Fault	5-31
7.4	Ground fault protection	0—2	2	2		0 = No action 2 = Fault	5-31
7.5	Motor thermal protection	0—2	1	2		0 = No action 1 = Warning 2 = Fault	5-32
7.6	Motor thermal protection break point current	50.0—150.0 % $\times I_{nMOTOR}$	1.0 %	100.0%			5-32
7.7	Motor thermal protection zero frequency current	5.0—150.0% $\times I_{nMOTOR}$	1.0 %	45.0%			5-33
7.8	Motor thermal protection time constant	0.5—300.0 minutes	0.5 min.	17.0 min.		Default value is set according to motor nominal current	5-33
7.9	Motor thermal protection break point frequency	10—500 Hz	1 Hz	35 Hz			5-34
7.10	Stall protection	0—2	1	1		0 = No action 1 = Warning 2 = Fault	5-34
7.11	Stall current limit	5.0—200.0% $\times I_{nMOTOR}$	1.0%	130.0%			5-35
7.12	Stall time	2.0—120.0 s	1.0 s	15.0 s			5-35
7.13	Maximum stall frequency	1— f_{max}	1 Hz	25 Hz			5-35
7.14	Underload protection	0—2	1	0		0 = No action 1 = Warning 2 = Fault	5-36
7.15	Underload prot., field weakening area load	10.0—150.0 % $\times T_{nMOTOR}$	1.0%	50.0%			5-36
7.16	Underload protection, zero frequency load	5.0—150.0% $\times T_{nMOTOR}$	1.0%	10.0%			5-36
7.17	Underload time	2.0—600.0 s	1.0 s	20.0s			5-36

Group 8, Autorestart parameters

Code	Parameter	Range	Step	Default	Custom	Description	Page
8. 1	Automatic restart: number of tries	0—10	1	0		0 = not in use	5-37
8. 2	Automatic restart:multi attempt maximum trial time	1—6000 s	1 s	30 s			5-37
8. 3	Automatic restart: start function	0—1	1	0		0 = Ramp 1 = Flying start	5-38
8. 4	Automatic restart of undervoltage	0—1	1	0		0 = No 1 = Yes	5-38
8. 5	Automatic restart of overvoltage	0—1	1	0		0 = No 1 = Yes	5-38
8. 6	Automatic restart of overcurrent	0—1	1	0		0 = No 1 = Yes	5-38
8. 7	Automatic restart of reference fault	0—1	1	0		0 = No 1 = Yes	5-38
8. 8	Automatic restart after over/undertemperature fault	0—1	1	0		0 = No 1 = Yes	5-38

Table 5.5-1 Special parameters, Groups 2—8.

5.5.2 Description of Groups 2—8 parameters

2. 1 Start/Stop logic selection

- 0: DIA1: closed contact = start forward
DIA2: closed contact = start reverse,
See figure 5.5-1.




Figure 5.5-1 Start forward/Start reverse.

- ① The first selected direction has the highest priority
- ② When DIA1 contact opens, the direction of rotation starts to change
- ③ If Start forward (DIA1) and Start reverse (DIA2) signals are active simultaneously, the Start forward signal (DIA1) has priority.

- 1: DIA1: closed contact = start open contact = stop
DIA2: closed contact = reverse open contact = forward
See figure 5.5-2.




Figure 5.5-2 Start, Stop, reverse.

- 2: DIA1: closed contact = start open contact = stop
 DIA2: closed contact = start enabled open contact = start disabled
- 3: 3-wire connection (pulse control):
 DIA1: closed contact = start pulse
 DIA2: closed contact = stop pulse
 (DIA3 can be programmed for reverse command)
 See figure 5.5-3.




Figure 5.5-3 Start pulse /Stop pulse.

2. 2 DIA3 function

- | | | |
|-----------------------------------|-----------------|---|
| 1: External fault, | closing contact | = Fault is shown and motor is stopped when the input is active |
| 2: External fault, | opening contact | = Fault is shown and motor is stopped when the input is not active |
| 3: Run enable | contact open | = Start of the motor disabled |
| | contact closed | = Start of the motor enabled |
| 4: Acc. / Dec time select. | contact open | = Acceleration/Deceleration time 1 selected |
| | contact closed | = Acceleration/Deceleration time 2 selected |
| 5: Reverse | contact open | = Forward |
| | contact closed | = Reverse |
| | | Can be used for reversing if parameter 2. 1 has value 3 |
| 6: Jog speed. | contact closed | = Jog speed selected for freq. reference |
| 7: Fault reset | contact closed | = Resets all faults |
| 8: Acc./Dec. operation prohibited | contact closed | = Stops acceleration or deceleration until the contact is opened |
| 9: DC-braking command | contact closed | = In Stop mode, the DC-braking operates until the contact is opened, see figure 5.5-4. DC-brake current is set with parameter 4. 8. |




Figure 5.5-4 DIA3 as DC-brake command input: a) Stop-mode = Ramp,
b) Stop-mode = Coasting.

2. 3 DIB4 function

Selections are same as in 2. 2 except :

10: Multi-Step contact closed = Selection 1 active
speed select 1

2. 4 DIB5 function

Selections are same as in 2. 2 except :

10: Multi-Step contact closed = Selection 2 active
speed select 2

11: Motor pot. UP contact closed = Reference decreases until the contact is opened

2. 5 DIB6 function

Selections are same as in 2. 2 except :

10: Multi-Step contact closed = Selection 3 active
speed select 3

11: Motor pot. DOWN contact closed = Reference decreases until the contact is opened

2. 6 V_{in} signal range

0 = Signal range 0—+10 V

1 = Custom setting range from custom minimum (par. 2. 4) to custom maximum (par. 2. 5)

2 = Signal range -10—+10 V , can be used only with Joystick control

2. 7 V_{in} custom setting minimum/maximum

2. 8 With these parameters, V_{in} can be set for any input signal span within 0—10 V.

Minimum setting: Set the V_{in} signal to its minimum level, select parameter 2. 7, press the Enter button

Maximum setting: Set the V_{in} signal to its maximum level, select parameter 2. 8, press the Enter button

Note! These parameters can only be set with this procedure (not with arrow up/arrow down buttons)

2. 9 V_{in} signal inversion

Parameter 2. 9 = 0, no inversion of analog V_{in} signal.

Parameter 2. 9 = 1, inversion of analog V_{in} signal.

2. 10 V_{in} signal filter time

Filters out disturbances from the incoming analog V_{in} signal.

A long filtering time makes regulation response slower.

See figure 5.5-5.




Figure 5.5-5 V_{in} signal filtering.

2. 11 Analog input I_{in} signal range

0 = 0—20 mA

1 = 4—20 mA

2 = Custom signal span

2. 12 Analog input I_{in} custom
2. 13 setting minimum/maximum

With these parameters, the scaling of the input current signal (I_{in}) range can be set between 0—20 mA.

Minimum setting:

Set the I_{in} signal to its minimum level, select parameter 2. 12, press the Enter button

Maximum setting:

Set the I_{in} signal to its maximum level, select parameter 2. 13, press the Enter button

Note! These parameters can only be set with this procedure (not with arrow up/arrow down buttons)

2. 14 Analog input I_{in} inversion

Parameter 2. 14 = 0, no inversion of I_{in} input

Parameter 2. 14 = 1, inversion of I_{in} input.

2. 15 Analog input I_{in} filter time

Filters out disturbances from the incoming analog I_{in} signal. A long filtering time makes regulation response slower. See figure 5.5-6.




Figure 5.5-6 Analog input I_{in} filter time.

5

2. 16 V_{in} signal minimum scaling

Sets the minimum scaling point for V_{in} signal. See figure 5.5-7.

2. 17 V_{in} signal maximum scaling

Sets the maximum scaling point for V_{in} signal. See figure 5.5-7.

2. 18 I_{in} signal minimum scaling

Sets the minimum scaling point for I_{in} signal. See figure 5.5-7.

2. 19 I_{in} signal maximum scaling

Sets the maximum scaling point for I_{in} signal. See figure 5.5-7.




Figure 5.5-7 Examples of the scaling of V_{in} and I_{in} inputs .

2. 20 Free analog input signal

Selection of input signal of free analog input (an input not used for reference signal):

- 0 = Not in use
- 1 = Voltage signal V_{in}
- 2 = Current signal I_{in}

2. 21 Free analog input signal function


This parameter sets the function of the free analog input:

- 0 = Function is not used
- 1 = Reducing motor current limit (par. 1. 7)

This signal will adjust the maximum motor current between 0 and parameter 1. 7 set max. limit.

See figure 5.5-8.


Figure 5.5-8 Reducing of max. motor current.



- 2 = Reducing DC brake current.

The DC braking current can be reduced, with the free analog input signal, between $0.15 \times I_{nCX}$ and current set by parameter 4. 8. See figure 5.5-9.

Figure 5.5-9 Reducing DC brake current.




3 Reducing acceleration and deceleration times.

The acceleration and deceleration times can be reduced with the free analog input signal, according to the following formula:

Reduced time = set acc./decel time (par. 1. 3, 1. 4; 4. 3, 4. 4) divided by the factor R from figure 5.5-10.


Figure 5.5-10 Reducing acceleration and deceleration times.



4 Reducing torque supervision limit.

The set torque supervision limit can be reduced with the free analog input signal between 0 and set supervision limit (par. 3. 14), see figure 5.5-11.

Figure 5.5-11 Reducing torque supervision limit.



2. 22 Motor potentiometer ramp time

Defines how fast the electronic motor (digital) potentiometer value changes.

3.1 Analog output function

See table on page 5-10.

3.2 Analog output filter time

Filters the analog output signal.
See figure 5.5-12.




Figure 5.5-12 Analog output filtering.

3.3 Analog output invert

Inverts analog output signal:

max output signal = minimum set value

min output signal = maximum set value




Figure 5.5-13 Analog output invert.

3.4 Analog output minimum


Defines the signal minimum to be either 0 mA or 4 mA. See figure 5.5-14.

3.5 Analog output scale

Scaling factor for analog output.
See figure 5.5-14.

Signal	Max. value of the signal
Output frequency	Max. frequency (p. 1. 2)
Motor speed	Max. speed ($n_n \times f_{\max} / f_n$)
Output current	$2 \times I_{nCX}$
Motor torque	$2 \times T_{nMot}$
Motor power	$2 \times P_{nMot}$
Motor voltage	$100\% \times U_{nMot}$
DC-link volt.	1000 V

Figure 5.5-14 Analog output scale.



- 3. 6 Digital output function**
3. 7 Relay output 1 function
3. 8 Relay output 2 function

Setting value	Signal content
0 = Not used	Out of operation <u>Digital output DO1 sinks current and programmable relay (RO1, RO2) is activated when:</u>
1 = Ready	The drive is ready to operate
2 = Run	The drive operates (motor is running)
3 = Fault	A fault trip has occurred
4 = Fault inverted	A fault trip <u>has not</u> occurred
5 = SV9000 overheat warning	The heat-sink temperature exceeds +70°C
6 = External fault or warning	Fault or warning depending on parameter 7. 2
7 = Reference fault or warning	Fault or warning depending on parameter 7. 1 - if analog reference is 4—20 mA and signal is <4mA
8 = Warning	Always if a warning exists
9 = Reversed	The reverse command has been selected
10= Jog speed	Jog speed has been selected with digital input
11 = At speed	The output frequency has reached the set reference
12= Motor regulator activated	Overvoltage or overcurrent regulator was activated
13= Output frequency supervision 1	The output frequency goes outside of the set supervision Low limit/ High limit (par. 3. 9 and 3. 10)
14= Output frequency supervision 2	The output frequency goes outside of the set supervision Low limit/ High limit (par. 3. 11 and 3. 12)
15= Torque limit supervision	The motor torque goes outside of the set supervision Low limit/ High limit (par. 3. 13 and 3. 14)
16= Reference limit supervision	Reference goes outside of the set supervision Low limit/ High limit (par. 3. 15 and 3. 16)
17= External brake control	External brake ON/OFF control with programmable delay (par 3. 17 and 3. 18)
18= Control from I/O terminals	External control mode selected with prog. pushbutton #2
19= Drive	Temperature on drive goes outside the set temperature supervision limits (par. 3. 19 and 3. 20)
20= Unrequested rotation direction	Rotation direction of the motor shaft is different from the requested one
21 = External brake control inverted	External brake ON/OFF control (par. 3.17 and 3.18), output active when brake control is OFF

Table 5.5-2 Output signals via DO1 and output relays RO1 and RO2.

- 3. 9 Output frequency limit 1, supervision function**
3. 11 Output frequency limit 2, supervision function

0 = No supervision
 1 = Low limit supervision
 2 = High limit supervision

If the output frequency goes under/over the set limit (3. 10, 3. 12) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8.

- 3. 10 Output frequency limit 1, supervision value**
3. 12 Output frequency limit 2, supervision value

The frequency value to be supervised by the parameter 3. 9 (3. 11).


See figure 5.5-15.

3. 13 Torque limit , supervision function

0 = No supervision
 1 = Low limit supervision
 2 = High limit supervision

If the calculated torque value goes under/over the set limit (3. 14) this function generates a warning message via the digital output DO1, via a relay output RO1 or RO2 depending on the settings of parameters 3. 6—3. 8.

Figure 5.5-15 Output frequency supervision.



3. 14 Torque limit , supervision value

The calculated torque value to be supervised by the parameter 3. 13.

3. 15 Reference limit , supervision function

0 = No supervision
 1 = Low limit supervision
 2 = High limit supervision

If the reference value goes under/over the set limit (3. 16) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8. The supervised reference is the current active reference. It can be source A or B reference depending on DIB6 input or the panel reference if panel is the active control source.

3. 16 Reference limit , supervision value

The frequency value to be supervised by the parameter 3. 15.

3. 17 External brake-off delay

3. 18 External brake-on delay

The function of the external brake can be delayed from the start and stop control signals with these parameters. See figure 5.5-16.

The brake control signal can be programmed via the digital output DO1 or via one of relay outputs RO1 and RO2, see parameters 3. 6—3. 8.

3. 19 Drive temperature limit supervision function

0 = No supervision
 1 = Low limit supervision
 2 = High limit supervision

If the temperature of the drive goes under/over the set limit (3. 20) this function generates a warning message via the digital output DO1 or via a relay output RO1 or RO2 depending on the settings of the parameters 3. 6—3. 8.

3. 20 Drive temperature limit value

The temperature value to be supervised by the parameter 3. 19.




Figure 5.5-16 External brake control: a) Start/Stop logic selection par. 2. 1 = 0, 1 or 2
b) Start/Stop logic selection par. 2. 1 = 3.

4. 1 Acc/Dec ramp 1 shape


4. 2 Acc/Dec ramp 2 shape

The acceleration and deceleration ramp shape can be programmed with these parameters. Setting value 0 gives a linear ramp shape which causes acceleration and deceleration to act immediately to the changes in the reference signal with the time constant set by the parameter 1. 3 and 1. 4 (4. 3 and 4. 4).

Setting value 0.1—10 seconds for 4. 1 (4. 2) causes an S-shape ramp. Parameter 1. 3 and 1. 4 (4. 3 and 4. 4) determines the time constant of acceleration/ deceleration in the middle of the curve.

See figure 5.5-17.

Figure 5.5-17 S-shaped acceleration/ deceleration.



4.3 Acceleration time 2**4.4 Deceleration time 2**

These values correspond to the time required for the output frequency to accelerate from the set minimum frequency (par. 1. 1) to the set maximum frequency (par. 1. 2). With this parameter it is possible to set two different acceleration/ deceleration times for one application. The active set can be selected with the programmable signal DIA3 of this application, see parameter 2. 2.

Acceleration/deceleration times can be reduced with a external free analog input signal, see parameters 2. 18 and 2. 19.

4.5 Brake chopper

0 = No brake chopper

1 = Brake chopper and brake resistor installed

2 = External brake chopper

When the drive is decelerating the motor, the energy stored in the inertia of the motor and the load is fed into the external brake resistor. This enables the drive to decelerate the load with the torque equal to that of acceleration, if the brake resistor is selected correctly. See separate Brake resistor installation manual.

4.6 Start function

Ramp:

- 0** The drive starts from 0 Hz and accelerates to the set reference frequency within the set acceleration time. (Load inertia or starting friction may cause prolonged acceleration times).

Flying start:

- 1** The drive is able to start into a running motor by applying a small torque to motor and searching for frequency corresponding to the speed the motor is running. Searching starts from the maximum frequency towards the actual frequency until the correct value is detected. The output frequency will then accelerate/ decelerate to the set reference value at a rate determined by the acceleration/ deceleration parameters.

Use this mode if the motor may be coasting when the start command is given. With the flying start it is possible to ride through short utility voltage interruptions.

4.7 Stop function

Coasting:

- 0** The motor coasts to an uncontrolled stop with the SV9000 off, after the Stop command.

Ramp:

- 1** After the Stop command, the speed of the motor is decelerated according to the deceleration ramp time parameter.
If the regenerated energy is high it may be necessary to use an external braking resistor for faster deceleration.

4.8 DC braking current

Defines the current injected into the motor during the DC braking.

4.9 DC braking time at stop

Defines if braking is ON or OFF and braking time of the DC-brake when the motor is stopping. The function of the DC-brake depends on the stop function, parameter 4. 7. See figure 5.5-18.

0 DC-brake is not used

>0 DC-brake is in use and its function depends on the Stop function, (param. 4. 7), and the time depends on the value of parameter 4. 9:

Stop-function = 0 (coasting):

After the stop command, the motor will coast to a stop with the SV9000 off.

With DC-injection, the motor can be electrically stopped in the shortest possible time, without using an optional external braking resistor.

The braking time is scaled according to the frequency when the DC-braking starts. If the frequency is \geq nominal frequency of the motor (par. 1.11), setting value of parameter 4.9 determines the braking time. When the frequency is $\leq 10\%$ of the nominal, the braking time is 10% of the set value of parameter 4.9.




Figure 5.5-18 DC-braking time when stop = coasting.

Stop-function = 1 (ramp):

After the Stop command, the speed of the motor is reduced based on the deceleration parameter ramp parameter, if no regeneration occurs due to load inertia, to a speed defined with parameter 4. 10, where the DC-braking starts.

The braking time is defined with parameter 4. 9.

If high inertia exists, it is recommended to use an external braking resistor for faster deceleration. See figure 5.5-19.




Figure 5.5-19 DC-braking time when stop function = ramp


4. 10 Execute frequency of DC-brake during ramp Stop

See figure 5.5-19.

4. 11 DC-brake time at start

- 0** DC-brake is not used
- >0** DC-brake is active when the start command is given. This parameter defines the time before the brake is released. After the brake is released the output frequency increases according to the set start function parameter 4. 6 and the acceleration parameters (1. 3, 4. 1 or 4. 2, 4. 3). See figure 5.5-20.

Figure 5.5-20 DC-braking at start.

**4. 12 - 4. 18 Multi-Step speeds 1-7**

These parameter values define the Multi-step speeds selected with the DIA4, DIB5 and DIB6 digital inputs. The selection of Multi-step speeds will occur similarly as described in the table 3.4-2 page 3-8.

5. 1 Prohibit frequency area**5. 2 Low limit/High limit**

5. 3

5. 4


5. 5

5. 6

In some systems it may be necessary to avoid certain frequencies because of mechanical resonance problems.

With these parameters it is possible to set limits for three "skip frequency" regions. The accuracy of the setting is 0.1 Hz.

Figure 5.5-21 Example of prohibit frequency area setting

**6. 1 Motor control mode**

0 = Frequency control:

The I/O terminal and panel references are frequency references and the drive controls the output frequency (output frequency resolution = 0.01 Hz)

1 = Speed control:

The I/O terminal and panel references are speed references and the drive controls the motor speed (regulation accuracy $\pm 0.5\%$).

6.2 Switching frequency

Motor noise can be minimized using a high switching frequency. Increasing the switching frequency reduces the capacity of the SV9000.

Before changing the frequency from the factory default 10 kHz (3.6 kHz \geq 40 Hp), check the drive derating from the curves in figures 5.2-2 and 5.2-3 in the User's Manual.

6.3 Field weakening point

6.4 Voltage at the field weakening point

The field weakening point is the output frequency at which the output voltage reaches the set maximum value (par. 6. 4). Above this frequency the output voltage remains at the set maximum value.

Below that frequency the output voltage depends on the setting of the V/Hz curve parameters 1. 8, 1. 9, 6. 5, 6. 6 and 6. 7. See figure 5.5-22.

When the parameters 1. 10 and 1. 11, nominal voltage and nominal frequency of the motor are set, parameters 6. 3 and 6. 4 are also set automatically to the corresponding values. If you need different values for the field weakening point and the maximum output voltage, change these parameters after setting parameters 1. 10 and 1. 11.

6.5 V/Hz curve, middle point frequency

If the programmable V/Hz curve has been selected with parameter 1. 8, this parameter defines the middle point frequency of the curve. See figure 5.5-22.

6.6 V/Hz curve, middle point voltage

If the programmable V/Hz curve has been selected with parameter 1. 8 this parameter defines the middle point voltage of the curve. See figure 5.5-22.

6.7 Output voltage at zero frequency

If the programmable V/Hz curve has been selected with parameter 1. 8 this parameter defines the zero frequency voltage of the curve. See figure 5.5-22.




Figure 5.5-22 Programmable V/Hz curve.

6.8 Overvoltage controller
6.9 Undervoltage controller

These parameters allow the over/undervoltage controllers to be switched out of operation. This may be useful, for example, if the utility supply voltage varies more than -15%—+10% and the application will not tolerate this over-/undervoltage. The regulator controls output frequency according to the supply fluctuations.

Over/undervoltage trips may occur when controllers are switched out of operation.

7.1 Response to the reference fault

0 = No response

1 = Warning

2 = Fault, stop mode after fault according to parameter 4.7

3 = Fault, always coasting stop mode after fault

A warning or a fault action and message is generated if 4—20 mA reference signal is used and the signal falls below 4 mA. The information can also be programmed via digital output DO1 and via relay outputs RO1 and RO2.

7.2 Response to external fault

0 = No response

1 = Warning

2 = Fault, stop mode after fault according to parameter 4.7

3 = Fault, always coasting stop mode after fault

A warning or a fault action and message is generated from the external fault signal in the digital input DIA3. The information can also be programmed into digital output DO1 and into relay outputs RO1 and RO2.

7.3 Phase supervision of the motor

0 = No action

2 = Fault

Phase supervision of the motor ensures that the motor phases have approximately equal current.

7.4 Ground fault protection

0 = No action

2 = Fault

Ground fault protection ensures that the sum of the motor phase currents is zero. The standard overcurrent protection is always working and protects the frequency converter from ground faults with high current levels.

Parameters 7.5—7.9 Motor thermal protection

General

Motor thermal protection is to protect the motor from overheating. The SV9000 drive is capable of supplying higher than nominal current to the motor. If the load requires this high current there is a risk that motor will be thermally overloaded. This is true especially at low frequencies. With low frequencies the cooling effect of the motor fan is reduced and the capacity of the motor is reduced. If the motor is equipped with an external fan the load reduction on low speed is small.

Motor thermal protection is based on a calculated model and it uses the output current of the drive to determine the load on the motor. When the power is turned on to the drive, the calculated model uses the heatsink temperature to determine the initial thermal stage for the motor. The calculated model assumes that the ambient temperature of the motor is 40°C.

Motor thermal protection can be adjusted by setting several parameters. The thermal current I_T specifies the load current above which the motor is overloaded. This current limit is a function of the output frequency. The curve for I_T is set with parameters 7. 6, 7. 7 and 7. 9, refer to the figure 5.5-23. The default values of these parameters are set from the motor nameplate data.

With the output current at I_T the thermal stage will reach the nominal value (100%). The thermal stage changes by the square of the current. With output current at 75% from I_T the thermal stage will reach 56% value and with output current at 120% from I_T the thermal stage would reach 144% value. The function will trip the device (refer par. 7. 5) if the thermal stage will reach a value of 105%. The response time of the thermal stage is determined with the time constant parameter 7. 8. The larger the motor the longer it takes to reach the final temperature.

The thermal stage of the motor can be monitored through the display. Refer to the table for monitoring items. (User's Manual, table 7.3-1).



CAUTION! *The calculated model does not protect the motor if the airflow to the motor is reduced by blocked air intake grill, dirt or dust.*

7. 5 Motor thermal protection

Operation:

0 = Not in use

1 = Warning

2 = Trip function

Tripping and warning will give a display indication with the same message code. If tripping is selected the drive will stop and activate the fault stage.

Deactivating the protection by setting this parameter to 0, will reset the thermal stage of the motor to 0%.

7. 6 Motor thermal protection, break point current

The current can be set between 50.0—150.0% $\times I_{nMotor}$.

This parameter sets the value for thermal current at frequencies above the break point on the thermal current curve. Refer to the figure 5.5-23.

The value is set in percentage of the motor nameplate data of the motor, parameter 1. 13, not the drive's nominal output current.

The motor's nominal current is the current which the motor can withstand in direct on-line use without being overheated.

If parameter 1. 13 is adjusted, this parameter is automatically restored to the default value.

Setting this parameter (or parameter 1. 13) does not affect the maximum output current of the drive. Parameter 1. 7 alone determines the maximum output current of the drive.




Figure 5.5-23 Motor thermal current I_T curve.

7.7 Motor thermal protection, zero frequency current

The current can be set between 10.0—150.0% $\times I_{nMotor}$. This parameter sets the value for thermal current at zero frequency. Refer to the figure 5.5-23.

The default value is set assuming that there is no external fan cooling the motor. If an external fan is used this parameter can be set to 90% (or higher).

The value is set as a percentage of the motor's nameplate nominal current, parameter 1. 13, not the drive's nominal output current. The motor's nominal current is the current which the motor can stand in direct on-line use without being overheated.

If you change the parameter 1. 13 this

parameter is automatically restored to the default value.

Setting this parameter (or parameter 1. 13) does not affect to the maximum output current of the drive. Parameter 1. 7 alone determines the maximum output current of the drive.

7.8 Motor thermal protection, time constant

This time can be set between 0.5—300 minutes.

This is the thermal time constant of the motor. The larger the motor the greater the time constant. The time constant is defined as the time that it takes the calculated thermal stage to reach 63% of its final value.

The motor thermal time is specific to a motor design and it varies between different motor manufacturers.

The default value for the time constant is calculated based on the motor name plate data from parameters 1. 12 and 1. 13. If either of these parameters is reset, then this parameter is set to its default value.

If the motor's t_6 -time is known (given by the motor manufacturer) the time constant

parameter could be set based on t_6 -time. As a rule of thumb, the motor thermal time constant in minutes equals to $2 \times t_6$ (t_6 in seconds is the time a motor can safely operate at six times the rated current). If the drive is in the stop stage the time constant is internally increased to three times the set parameter value. The cooling in the stop stage is based on convection with an increased time constant.

7.9 Motor thermal protection, break point frequency

This frequency can be set between 10—500 Hz.

This is the frequency break point of thermal current curve. With frequencies above this point the thermal capacity of the motor is assumed to be constant. Refer to the figure 5.5-23.

The default value is based on motor's nameplate data, parameter 1. 11. It is 35 Hz for a 50 Hz motor and 42 Hz for a 60 Hz motor. More generally it is 70% of the frequency at the field weakening point (parameter 6. 3). Changing either parameter 1. 11 or 6. 3 will restore this parameter to its default value.




Figure 5.5-24 Calculating motor temperature.

Parameters 7. 10— 7. 13, Stall protection

General

Motor stall protection protects the motor from short time overload situations like a stalled shaft. The reaction time of stall protection can be set shorter than with motor thermal protection. The stall state is defined with two parameters, 7.11. Stall Current and 7.13. Stall Frequency. If the current is higher than the set limit and output frequency is lower than the set limit the stall state is true. There is actually no real indication of the shaft rotation. Stall protection is a type of overcurrent protection.

5

7. 10 Stall protection

Operation:

0 = Not in use

1 = Warning

2 = Trip function

Tripping and warning will give a display indication with the same message code. If tripping is set on, the drive will stop and activate the fault stage.


Setting this parameter to 0 will deactivate the protection and will reset the stall time counter to zero.

7. 11 Stall current limit

The current can be set between 0.0—200% x I_{nMotor} .

In the stall stage the current has to be above this limit. Refer to the figure 5.5-25. The value is set as a percentage of the motor's nameplate nominal current, parameter 1. 13, motor's nominal current. If parameter 1.13 is adjusted, this parameter is automatically restored to its default value.

Figure 5.5-25 Setting the stall characteristics.



7. 12 Stall time

The time can be set between 2.0—120 s.

This is the maximum allowed time for a stall stage. There is an internal up/down counter to count the stall time. Refer to the figure 5.5-26.

If the stall time counter value goes above this limit the protection will cause a trip (refer to the parameter 7. 10).

7. 13 Maximum stall frequency

The frequency can be set between 1— f_{max} (par. 1. 2).

In the stall state, the output frequency has to be smaller than this limit. Refer to the figure 5.5-25.




Figure 5.5-26 Counting the stall time.

Parameters 7. 14— 7. 17, Underload protection General

The purpose of motor underload protection is to ensure that there is load on the motor while the drive is running. If the motor load is reduced, there might be a problem in the process, e.g. broken belt or dry pump.

Motor underload protection can be adjusted by setting the underload curve with parameters 7. 15 and 7. 16. The underload curve is a squared curve set between zero frequency and the field

weakening point. The protection is not active below 5Hz (the underload counter value is stopped). Refer to the figure 5.5-27.

The torque values for setting the underload curve are set with percentage values which refer to the nominal torque of the motor. The motor's nameplate data, parameter 1. 13, the motor's nominal current

and the drive's nominal current I_{CT} are used to find the scaling ratio for the internal torque value. If other than a standard motor is used with the drive, the accuracy of the torque calculation is decreased.

7. 14 Underload protection

Operation:

0 = Not in use

1 = Warning

2 = Fault

Tripping and warning will give a display indication with the same message code. If tripping is set active the drive will stop and activate the fault stage.

Deactivating the protection, by setting this parameter to 0, will reset the underload time counter to zero.

7. 15 Underload protection, field weakening area load

The torque limit can be set between 20.0—150 % $\times T_{nMotor}$.

This parameter is the value for the minimum allowed torque when the output frequency is above the field weakening point.

Refer to the figure 4.5-22.

If parameter 1. 13 is adjusted, this parameter is automatically restored to its default value.




Figure 5.5-27 Setting of minimum load.

7. 16 Underload protection, zero frequency load

Torque limit can be set between 10.0—150 % $\times T_{nMotor}$.

This parameter is the value for the minimum allowed torque with zero frequency. Refer to the figure 5.5-27. If parameter 1. 13 is adjusted, this parameter is automatically restored to its default value.

7. 17 Underload time

This time can be set between 2.0—600.0 s.

This is the maximum allowed time for an underload state. There is an internal up/down counter to accumulate the underload time. Refer to the figure 5.5-28.

If the underload counter value goes above this limit, the protection will cause a trip (refer to the parameter 7. 14). If the drive is stopped the underload counter is reset to zero.




Figure 5.5-28 Counting the underload time.

8.1 Automatic restart: number of tries

8.2 Automatic restart: trial time

The Automatic restart function restarts the drive after the faults selected with parameters 8. 4—8. 8. The Start function for Automatic restart is selected with parameter 8. 3.




Figure 5.5-29 Automatic restart

Parameter 8. 1 determines how many automatic restarts can be made during the trial time set by the parameter 8. 2.

The time counting starts from the first autorestart. If the number of restarts does not exceed the value of the parameter 8. 1 during the trial time, the counting is cleared after the trial time has elapsed. The next fault starts the counting again.

8.3 Automatic restart, start function

The parameter defines the start mode:

- 0 = Start with ramp
- 1 = Flying start, see parameter 4. 6.

8.4 Automatic restart after undervoltage trip

- 0 = No automatic restart after undervoltage fault trip
- 1 = Automatic restart after undervoltage fault condition returns to the normal condition (DC-link voltage returns to the normal level)

8.5 Automatic restart after overvoltage trip

- 0 = No automatic restart after overvoltage fault trip
- 1 = Automatic restart after overvoltage fault condition returns to the normal condition (DC-link voltage returns to the normal level)

8.6 Automatic restart after overcurrent trip

- 0 = No automatic restart after overcurrent fault trip
- 1 = Automatic restart after overcurrent faults

8.7 Automatic restart after reference fault trip

- 0 = No automatic restart after reference fault trip
- 1 = Automatic restart after analog current reference signal (4—20 mA) returns to the normal level (≥ 4 mA)

8.8 Automatic restart after over-/undertemperature fault trip

- 0 = No automatic restart after temperature fault trip
- 1 = Automatic restart after heatsink temperature has returned to its normal level between -10°C — $+75^{\circ}\text{C}$.